

## Technical Data Sheet for AXIA MP-2

AXIA MP-2 is designed for the assembly of difficult-to-bond materials which require uniform stress distribution and strong tension and/or shear strength the product provides rapid bonding of a wide range of materials, including metals, plastics and elastomers. Product AXIA MP-2 is particularly suited for bonding porous or absorbent materials such as wood, leather and fabric.

### 1. Features

Chemical Type : Ethylcyanoacrylate  
Appearance : Colorless, transparent liquid  
Density(20 °C): 1.06  
Viscosity(25 °C, 60% RH, cps): 200  
Solubility : Acetone soluble  
Flash Point : 85 °C  
Cure Speed : Moderate

### 2. AXIA MP-2

Adherends	Set time(sec)	Shear strength (Kgf/cm <sup>2</sup> )
Steel	7~15	180
Aluminium	10~15	120
Stainless steel	7~15	180
Copper	10~15	150
ABS	7~15	60*
Acryl	5~10	60*
Rigid PVC	5~10	90*
Phenol	5~10	90*
Polycarbonate	7~15	90*
Chloroplen	5~10	5*
NBR	5~10	20*
Wood(White birch)	30~40	100*

\* Represents the fracture of the adherend

### 3. Temperature Resistance

Thermal resistance is excellent from -30°C to 85°C. Heating causes the adhesive to soften but strength is regained on cooling, provided 85°C is not exceeded for prolonged periods.

### 4. Direction of Use

Surface should be clean, dry and grease free prior to bonding. MEK and similar solvent can be used to degrease surfaces. For difficult or porous surface, try using activator like AXIA Spray Primer 802. When bonding polypropylene, polyethylene, PTFE, silicone, we would recommend priming first using AXIA 1502 or AXIA 2702.

### 5. Storage

Store in a cool and out of direct sun light. Refrigeration to 5~10°C gives optimum storage stability.

### 6. Health & Safety in Use

Danger - It bonds skin and eyes in seconds. If accidental skin bonding happens, wash with warm soapy water, In case of eye contact, flush with plenty of water and seek for medical advice.